



Room Thermostat

automatic opening and closing of skylights and windows



Room Thermostat

AUTOMATIC OPENING AND CLOSING OF SKYLIGHTS

The room thermostat can be used for automatic opening and closing of skylights when the temperature in the room exceeds the set temperature. There is approx. 1 degree between the open and close limit.

The room thermostat is often connected with an AUT-MAN switch so the opening can be controlled automatically or manually.

The room thermostat can also be connected with a weekly timer which makes sure that the window is closed automatically, e.g. during the night. Should be used together with a weather sensor in order to protect against opening in bad weather.

Dimensions: 75 x 75 x 25 mm

Colour: White

